


Throttle Position Sensor


1. INSPECT THROTTLE POSITION SENSOR

- Disconnect the throttle opener vacuum hose from the throttle body.
- Apply vacuum to the throttle opener.
- Insert a 0.54 mm (0.021 in.) or 0.70 mm (0.028 in.) feeler gauge between the throttle stop screw and stop lever.




- Using an ohmmeter, measure the resistance between each terminal.

Clearance between lever and stop screw	Between terminals	Resistance
0 mm (0 in.)	VTA-E2	0.34–6.3 Ω
0.54 mm (0.021 in.)	IDL-E2	0.5 k Ω or less
0.70 mm (0.028 in.)	IDL-E2	Infinity
Throttle valve fully Open	VTA-E2	2.4–11.2 k Ω
–	VC-E2	3.1–7.2 k Ω




2. IF NECESSARY, ADJUST THROTTLE POSITION SENSOR


- Loosen the 2 set screws of the sensor.




- Insert a 0.65 mm (0.026 in.) feeler gauge between the throttle stop screw and stop lever.



- Connect the tester probe of an ohmmeter to the terminals IDL and E2 of the sensor.




- (d) Gradually turn the sensor clockwise until the ohmmeter deflects, and secure it with the 2 set screws.



- (e) Recheck the continuity between terminals IDL and E2.

Clearance between lever and stop screw	Continuity (IDL-E2)
0.54 mm (0.021 in.)	Continuity
0.70 mm (0.028 in.)	No continuity

- (f) Reconnect the vacuum hose to the throttle body.



Sub-Throttle Actuator, Sub-Throttle Valve and Throttle Position Sensor

1. INSPECT SUB-THROTTLE ACTUATOR

Using an ohmmeter, measure the resistance between the terminals (ACM to A and A-, BCM to B and B-).


Resistance:


0.82–0.98 Ω at 20°C (68°F)

If the resistance is not as specified, replace the actuator.

2. REMOVE SUB-THROTTLE ACTUATOR


Remove the 4 screws and sub-throttle actuator.






3. INSPECT SUB-THROTTLE VALVE

Check that there is no clearance between the throttle stop screw and throttle valve gear when the subthrottle valve is fully closed.




4. INSPECT SUB-THROTTLE POSITION SENSOR

- Set the sub-throttle valve to fully closed position.
- Insert a 0.41 mm (0.016 in.) or 0.48 mm (0.019 in.) feeler gauge between the throttle stop screw and throttle valve gear.




- Using an ohmmeter, measure the resistance between terminals.


Clearance between lever and stop screw	Between terminals	Resistance
0 mm (0 in.)	VTA-E2	0.3–6.3 kΩ
0.41 mm (0.016 in.)	IDL-E2	0.5 kΩ or less
0.48 mm (0.019 in.)	IDL-E2	Infinity
Throttle valve fully open	VTA-E2	2.0–10.8 kΩ
–	VC-E2	3.5–6.5 kΩ




5. IF NECESSARY, ADJUST SUB-THROTTLE POSITION SENSOR

- Loosen the 2 set screws of the sensor.
- Set the sub-throttle valve to fully closed position.
- Insert a 0.45 mm (0.018 in.) feeler gauge, between the throttle stop screw and throttle valve gear.






- (d) Connect the tester probe of an ohmmeter to the terminals IDL and E2 of the sensor.




- (e) Gradually turn the sensor clockwise until the ohmmeter deflects, and secure it with the 2 set screws.



- (f) Recheck the continuity between terminals IDL and E2.

Clearance between lever and stop screw	Continuity (IDL-E2)
0.41 mm (0.016 in.)	Continuity
0.48 mm (0.019 in.)	No continuity



6. REINSTALL SUB-THROTTLE ACTUATOR

Install the sub-throttle actuator with the 4 screws.